


USER'S MANUAL

SETTING YOUR MUSE WATCH


Position 0 - Sealed watch

In this position, the crown is screwed fully against the watch case. Your MUSE watch is therefore waterproof to a depth of 50 metres.




Position 1 - Manual winding – Watch NON sealed

In this position, the crown is unscrewed. To make manual winding of the watch, you have to turn the crown clockwise. Anti-clockwise is inactive. When putting into service or following a stop of the watch, perform some 20 rounds of crown for a partial winding.



Position 2 – Time setting – Watch NON sealed

In this position, the crown is unscrewed and pulled out to position 2. The seconds disk continues to turn. Set the correct time by turning the crown forward or backward.




Commissioning:

- A. Unscrew the crown
- B. Perform manual winding of the watch (*position 1*).
- C. Perform the time setting (*position 2*).
- D. Screw back the crown (*position 0*).

To screw the crown, put it back in position 1 and apply slight pressure on it while screwing clockwise until it is in contact with the watch case.

After handling, screw carefully the crown against the case to guarantee the seal. The crown should not be manipulated under water.



DAILY USE OF YOUR MUSE

Your watch will not ask you much daily maintenance. You can maintain its brilliance with a microfiber cloth. You can also wash your MUSE from time to time with a soft brush and water soap. After a sea bath, it is important to rinse your watch with clear water to remove salt and sand.

Also note that the leather of your strap gets old and stains more easily when in contact with liquids under water.




MANUEL D'UTILISATION

RÉGLAGE DE VOTRE MONTRE MUSE


Position 0 - Montre étanche :

Dans cette position, la couronne est vissée à fond contre le boîtier. Votre montre MUSE est dès lors étanche jusqu'à 50 mètres de profondeur.




Position 1 - Remontage manuel - montre NON étanche :

Dans cette position, la couronne est dévissée. Pour effectuer le remontage manuel de la montre il faut tourner la couronne dans le sens horaire. L'autre sens est inactif. Lors d'une mise en service ou suite à un arrêt de la montre, effectuer quelques 20 tours de couronne pour un remontage partiel.



Position 2 - Mise à l'heure - montre NON étanche :


Dans cette position, la couronne est dévissée et tirée au premier cran. Le disque des secondes continue de tourner. Pour effectuer la mise à l'heure, tourner la couronne dans le sens qui convient.



Mise en service

- A. Dévisser la couronne
 - B. Effectuer un remontage manuel de la montre (*position 1*).
 - C. Effectuer la mise à l'heure (*position 2*).
 - D. Revisser la couronne (*position 0*).
- Pour revisser la couronne, la remettre en position 1 et appliquer une légère pression sur celle-ci tout en la vissant dans le sens horaire jusqu'à ce qu'elle soit en contact avec la boîte.*

Après toute manipulation, revisser soigneusement la couronne contre la boîte afin de garantir l'étanchéité. La couronne ne doit pas être manipulée sous l'eau.



ENTRETIEN DE VOTRE MUSE AU QUOTIDIEN

Votre montre ne vous demandera que peu d'entretien au quotidien. Vous pouvez maintenir son éclat au moyen d'un tissu en microfibre. Vous pouvez également laver votre MUSE de temps à autre avec une brosse douce et de l'eau savonneuse. Après un bain de mer, il est important de rincer votre montre à l'eau douce afin d'éliminer le sel et le sable.

A noter encore que le cuir vieillit et se tache plus facilement lorsqu'il est en contact avec des liquides.



MUSE
swiss art watches